




PARAGON  
FURNITURE INC.





## ASSEMBLY INSTRUCTION FOR 32-OS AND 39-OS


ITEM	DESCRIPTION	QTY.
1	LEFT END	1
2	RIGHT END	1
3	BACK PANEL	1
4	TOP	1
5	SHELF/BOTTOM	2
6	BASE	2

NOTE: ON THE 39-OS QTY OF 3

# HARDWARE LIST


		<u>QTY</u> 32-OS	<u>QTY</u> 39-OS
	POSI-LOCK STUD	36	40
	ADJUSTABLE GLIDE	4	4
	SLEEVE NUT	4	4
	SLEEVE NUT BOLT	4	4
	GROMMET	5	6
	 WIRE CHANNEL 24"	1	1

# STEP 1




INSTALL POSI LOCK STUDS IN HOLES EXCEPT WHERE NOTED ALSO SELECT DESIRED LOCATION FOR SHELF AND INSTALL POSI LOCK STUDS IN DESIRED HOLES.


# STEP 2



LAY TOP PANEL ON A CLEAN SCRATCH FREE SURFACE AND INSTALL 2 POSI LOCK STUDS.

**STEP 3**


1. THERE ARE 2 (ITEM 5) (3 IN THE 39-OS) 1 IS THE SHELF 1 IS THE BOTTOM IN THE BOTTOM  
INSTALL THE 2 POSI LOCK STUDS IN THE 2 HOLES PROVIDED. THE SHELF DOES NOT REQUIRE ANY  
POSI LOCK STUDS.

**STEP 5**

1. PLACE LEFT END PANEL (ITEM 1) ON A CLEAN SCRATCH FREE SURFACE.
2. WITH 2 PEOPLE INSTALL BACK PANEL (ITEM 3) BY SLIDING ONTO POSI LOCK STUDS AND LOCKING INTO PLACE (SEE PAGE 7)
3. INSTALL THE BOTTOM (ITEM 5) USING THE SAME METHODS.
4. INSTALL THE 2 BASES (ITEM 6).
5. INSTALL THE SHELF (ITEM 5).
6. INSTALL THE TOP (ITEM 4).
7. INSTALL THE RIGHT END PANEL (ITEM 2).
8. INSTALL THE LEVELING GLIDE INTO BOTTOM OF THE END PANELS.
9. TURN DESK UPRIGHT INSTALL GROMMETS.

SHOULD YOU NEED ASSISTANCE CALL YOUR DEALER OR PARAGON AT  
1-800-451-8546


## OPTIONAL





CIRCULATION DESK PIECES CAN BE CONNECTED TOGETHER.

- 1.LEVEL ALL PIECES TO BE CONNECTED.
- 2.THEN USING A 13/64" DRILL BIT DRILL THROUGH THE 4 PRE-DRILLED HOLES THAT WERE NOT USED ON PAGE 3.
- 3.INSTALL SLEEVE NUT AND BOLT AND TIGHTEN.

# CONNECTORS



## POSI-LOCK CONNECTORS



WIRE CHANNEL INSTALLS INSIDE CABINET ONTO BACK PANEL BETWEEN GROMMETS