





PARAGON
FURNITURE INC.



ASSEMBLY INSTRUCTION FOR 32-BR AND 39-BR


ITEM	DESCRIPTION	QTY.
1	LEFT END	1
2	RIGHT END	1
3	BACK PANEL	1
4	TOP	1
5	SHELF	1
6	BASE	1
7	BOOK DROP BRACKET	1

STEP 1




LAY END PANELS (ITEM 1 & 2) ON A CLEAN SCRATCH FREE SURFACE AND INSTALL POSI LOCK STUDS IN ALL HOLES EXCEPT WHERE NOTED.

STEP 2




LAY TOP PANEL (ITEM 4) ON A CLEAN SCRATCH FREE SURFACE AND INSTALL 2 POSI LOCK STUDS.

STEP 3




LAY SHELF (ITEM 5) ON A CLEAN SCRATCH FREE SURFACE AND INSTALL 3 POSI LOCK STUDS.

STEP 4

1. PLACE LEFT END PANEL (ITEM 1) ON A CLEAN SCRATCH FREE SURFACE.
2. WITH 2 PEOPLE INSTALL BACK PANEL (ITEM 3) BY SLIDING ONTO POSI LOCK STUDS AND LOCKING INTO PLACE (SEE PAGE 6)
3. INSTALL THE TOP (ITEM 4) USING THE SAME METHODS.
4. INSTALL THE BASE (ITEM 6).
5. INSTALL THE SHELF (ITEM 5).
6. INSTALL THE BOOK DROP BRACKET (ITEM 7).
7. INSTALL THE 4 LEVELING GLIDES
8. TURN UNIT UPRIGHT AND INSTALL THE 2 GROMMETS.

SHOULD YOU NEED ASSISTANCE CALL YOUR DEALER OR PARAGON AT
1-800-451-8546




OPTIONAL



CIRCULATION DESK PIECES CAN BE CONNECTED TOGETHER.






- 1.LEVEL ALL PIECES TO BE CONNECTED.
- 2.THEN USING A 13/64" DRILL BIT DRILL THROUGH THE 4 PRE-DRILLED HOLES THAT WERE NOT USED ON PAGE 3.
- 3.INSTALL SLEEVE NUT AND BOLT AND TIGHTEN.

CONNECTORS



WIRE CHANNEL INSTALLS INSIDE CABINET ONTO BACK PANEL BETWEEN GROMMETS

HARDWARE LIST

		QTY
		32-BR
		39-BR
	POSI-LOCK STUD	22
	ADJUSTABLE GLIDE	4
	SLEEVE NUT	4
	SLEEVE NUT BOLT	4
	GROMMET	2
	#8 X 5/8 BLACK PAN HEAD SCREW	3
	BOOK DROP BRACKET	1
	WIRE CHANNEL 24"	1