




PARAGON
FURNITURE INC.




**ASSEMBLY INSTRUCTION FOR
3936-DS, 3948-DS, 3960-DS, 3972-DS**


ITEM	DESCRIPTION	QTY.
1	RIGHT END	1
2	LEFT END	1
3	TOP	1
4	BACK PANEL	1
5	SHELF	1
6	ACCENT BASE	1
7	GUSSET	2 GUSSET ONLY ON 60" AND 72" DESK

HARDWARE LIST

QTY




ADJUSTABLE GLIDE




SLEEVE NUT



SLEEVE NUT BOLT



GROMMET




WIRE CHANNEL 24"

WIRE CHANNEL INSTALLS INSIDE CABINET ONTO
BACK PANEL BETWEEN GROMMETS


	3936-DS	3948-DS	3960-DS	3972-DS
ADJUSTABLE GLIDE	4	4	4	4
SLEEVE NUT	4	4	4	4
SLEEVE NUT BOLT	4	4	4	4
GROMMET	4	4	4	4
WIRE CHANNEL 24"	1	1	1	1

SHOULD YOU NEED ASSISTANCE CALL YOUR DEALER OR PARAGON AT
1-800-451-8546



1. INSTALL ADJUSTABLE GLIDES INTO BOTTOM OF END PANELS
2. USING 2 PEOPLE HAVE 1 PERSON HOLD THE LEFT END (ITEM 2) UPRIGHT TAKE THE BACK PANEL (ITEM 4) ATTACH IT BY SLIDING THE 2 CLIPS LOCATED ON THE SIDE EDGES OF THE BACK PANEL OVER THE SHOULDER SCREWS LOCATED ON THE REAR EDGE OF THE LEFT END PANEL. PUSH DOWN FIRMLY ON BACK TO ENSURE CHIPS ARE SECURELY FASTENED. SEE PAGE#
3. REPEAT PROCEDURE FOR RIGHT END (ITEM 1).
4. NEXT INSTALL TOP (ITEM 3) AND LOCK INTO PLACE
5. AT THIS POINT YOU MAY WANT TO LAY DESK ON ITS BACK FOR BETTER ACCESS TO SHELF AND BASE CONNECTORS. NOTE THIS IS NOT NECESSARY
6. INSTALL SHELF AND LOCK INTO PLACE
7. INSTALL BASE LOCK INTO PLACE
8. ON 60" AND 72" DESK IN STALL GUSSETS (ITEM 7)
9. TURN DESK UPRIGHT.


OPTIONAL




CIRCULATION DESK PIECES CAN BE CONNECTED TOGETHER.

- 1.LEVEL ALL PIECES TO BE CONNECTED.
- 2.THEN USING A 13/64" DRILL BIT DRILL THROUGH THE 4 PRE-DRILLED HOLES THAT WERE NOT USED ON PAGE 3.
- 3.INSTALL SLEEVE NUT AND BOLT AND TIGHTEN.

CONNECTORS



POSI-LOCK CONNECTORS



BACK PANEL CONNECTOR