





PARAGON
FURNITURE INC.



ASSEMBLY INSTRUCTION FOR PVA (PARAVISION ACCESSORY)

ITEM	DESCRIPTION	QTY.
1	RIGHT END	1
2	LEFT END	1
3	BOTTOM SHELF	1
4	MONITOR TUB 22 1/4"	1
5	GLASS	1
6	KEYBOARD TRAY 27"	1

HARDWARE LIST

		<u>QTY</u>
	POSI-LOCK STUD	14
	#8 X 5/8 BLACK PAN HEAD SCREW	12

1. REMOVE GUSSETS FROM DESK SHELL AND THEY WILL NOT BE USED AGAIN.
2. ASSEMBLE RIGHT END (ITEM 1), LEFT END (ITEM 2) AND LOWER SHELF (ITEM 3) BY ALIGNING THE POSI LOCK CONNECTORS AND TIGHTENING (SEE ILLUSTRATION)
3. WITH THE PVA ASSEMBLED PLACE UNDER DESK AND ALIGN WITH POSI LOCK STUDS THAT WERE USED TO HOLD THE GUSSETS IN PLACE. LOCK INTO PLACE.
4. INSTALL KEYBOARD TRAY WITH #8 X 5/8" PAN HEAD SCREWS NOTE FRONT EDGE OF TRAY SHOULD BE FLUSH WITH THE FRONT OF THE DESK TOP.
5. INSTALL GLASS IN TOP
6. INSTALL MONITOR TUB INTO THE BRACKETS MOUNTED ON THE SIDES OF THE PVA NOTE THE ANGLE OF YOUR MONITOR CAN BE ADJUSTED BY MOVING THE SHOULDER BOLTS UP OR DOWN IN THE SLOTS

POSI-LOCK CONNECTORS

