





PARAGON
FURNITURE INC.



ASSEMBLY INSTRUCTION FOR PDA (PENCIL DRAWER ACCESSORY)



#8 X 5/8 BLACK (8 PER DRAWER)
PAN HEAD SCREW

1. PLACE DRAWER IN DESIRED LOCATION
AND SCREW INTO PLACE WITH SCREWS PROVIDED