




PARAGON
FURNITURE INC.




ASSEMBLY INSTRUCTION FOR 3236-DS, 3248-DS, 3260-DS, 3272-DS

ITEM	DESCRIPTION	QTY.
1	RIGHT END	1
2	LEFT END	1
3	TOP	1
4	BACK PANEL	1
5	SHELF	1
6	ACCENT BASE	1
7	GUSSET	2 GUSSET ONLY ON 60" AND 72" DESK

HARDWARE LIST


QTY



ADJUSTABLE GLIDE

3936-DS	3948-DS	3960-DS	3972-DS
---------	---------	---------	---------

4	4	4	4
---	---	---	---




SLEEVE NUT

4	4	4	4
---	---	---	---




SLEEVE NUT BOLT

4	4	4	4
---	---	---	---



GROMMET


4	4	4	4
---	---	---	---



WIRE CHANNEL 24"


1	1	1	1
---	---	---	---

WIRE CHANNEL INSTALLS INSIDE CABINET ONTO
BACK PANEL BETWEEN GROMMETS



1. INSTALL ADJUSTABLE GLIDES INTO BOTTOM OF END PANELS
2. USING 2 PEOPLE HAVE 1 PERSON HOLD THE LEFT END (ITEM 2) UPRIGHT TAKE THE BACK PANEL (ITEM 4) ATTACH IT BY SLIDING THE 2 CLIPS LOCATED ON THE SIDE EDGES OF THE BACK PANEL OVER THE SHOULDER SCREWS LOCATED ON THE REAR EDGE OF THE LEFT END PANEL. PUSH DOWN FIRMLY ON BACK TO ENSURE CHIPS ARE SECURELY FASTENED. SEE PAGE#
3. REPEAT PROCEDURE FOR RIGHT END (ITEM 1).
4. NEXT INSTALL TOP (ITEM 3) AND LOCK INTO PLACE
5. AT THIS POINT YOU MAY WANT TO LAY DESK ON ITS BACK FOR BETTER ACCESS TO SHELF AND BASE CONNECTORS. NOTE THIS IS NOT NECESSARY
6. INSTALL SHELF AND LOCK INTO PLACE
7. INSTALL BASE LOCK INTO PLACE
8. ON 60" AND 72" DESK IN STALL GUSSETS (ITEM 7)
9. SLIDE TRANSACTION (ITEM#8)TOP ONTO STUDS AND LOCK INTO PLACE
10. TURN DESK UPRIGHT.



OPTIONAL



CIRCULATION DESK PIECES CAN BE CONNECTED TOGETHER.

- 1.LEVEL ALL PIECES TO BE CONNECTED.
- 2.THEN USING A 13/64" DRILL BIT DRILL THROUGH THE 4 PRE-DRILLED HOLES THAT WERE NOT USED ON PAGE 3.
- 3.INSTALL SLEEVE NUT AND BOLT AND TIGHTEN.

CONNECTORS



BACK PANEL CONNECTOR