


PARAGON  
FURNITURE INC.




## ASSEMBLY INSTRUCTION FOR 32-DS AND 39-DS

ITEM	DESCRIPTION	QTY.
1	LEFT END	1
2	RIGHT END	1
3	BACK PANEL	1
4	TOP	1
5	BOTTOM	1
6	ADJUSTABLE SHELF	1

NOTE: ON THE 39-DS QTY OF 2

# HARDWARE LIST




CAM  
SCREW

QTY  
32-DS

QTY  
39-DS

18

18





SHELF  
SUPPORT

4

8

1010588

## STEP 1



INSTALL CAM SCREWS IN ALL HOLES **NOT** LABELED **SHELF HOLES**.

## STEP 2

1. REFER TO DRAWING ON PAGE 1.
2. LAY LEFT END PANEL (ITEM 1) ON A CLEAN SCRATCH FREE SURFACE.
3. INSTALL BACK (ITEM 3) BY SLIDING ONTO CAM SCREWS AND LOCKING INTO PLACE (SEE PAGE 3).
4. INSTALL TOP (ITEM 4 ) USING THE SAME METHODS.
5. INSTALL BOTTOM (ITEM 5).
6. INSTALL RIGHT END (ITEM 2).
7. TURN DICTIONARY STAND UPRIGHT.
8. INSTALL ADJUSTABLE SHELVES (ITEM 6).

SHOULD YOU NEED ASSISTANCE CALL YOUR DEALER OR PARAGON AT  
1-800-451-8546

# CONNECTORS

