












PARAGON
FURNITURE INC.




ASSEMBLY INSTRUCTION FOR 32-2D AND 39-2D

ITEM	DESCRIPTION	QTY.	ITEM	DESCRIPTION	QTY.
1	LEFT END	1	8	DRAWER	2
2	RIGHT END	1	9	BASE	2
3	BACK PANEL	1			
4	TOP	1			
5	SHELF/BOTTOM	2			
6	UPPER BOTTOM	1			
7	PARTITION	1			

HARDWARE LIST

	<u>QTY</u>
 POSI-LOCK STUD	32-2D 39-2D 40
 ADJUSTABLE GLIDE	4
 SLEEVE NUT	4
 SLEEVE NUT BOLT	4
 DRAWER PULL SCREW	4
 DRAWER SLIDE	4
 #6 X 1/2"	20
 #6 X 3/4" FLAT HEAD SCREW	4
 LOCK CLIP	2
 DRAWER LOCK	2
 DRAWER PULL	2
 GROMMET	5
 WIRE CHANNEL 24"	1


STEP 1



1. LAY END PANELS ON A CLEAN SCRATCH FREE SURFACE AND INSTALL DRAWER SLIDES WITH 3 #6 X 1/2" SCREWS IN EACH DRAWER SLIDE.

2. INSTALL POSI LOCK STUDS IN HOLES EXCEPT WHERE NOTED ALSO SELECT DESIRED LOCATION FOR SHELF AND INSTALL POSI LOCK STUDS IN DESIRED HOLES.


STEP 2



1. LAY TOP PANEL ON A CLEAN SCRATCH FREE SURFACE AND INSTALL 4 POSI LOCK STUDS.


2. INSTALL LOCK CLIPS USING 2 #6 X 1/2" SCREWS IN EACH LOCK CLIP.

STEP 3




1. THERE ARE 2 ITEM #5. 1 IS THE SHELF AND 1 IS THE BOTTOM IN THE BOTTOM INSTALL 2 POSI LOCK STUDS IN THE 2 HOLES PROVIDED.
THE SHELF DOES NOT REQUIRE ANY POSI LOCK STUDS.

STEP 4




1. (ITEM 7) PARTITION (INSTALL DRAWER SLIDES ONTO BOTH SIDES OF THE PARTITION USING 3 #6 X 1/2" ON EACH SIDE)

STEP 5



1. (ITEM 6) UPPER BOTTOM (INSTALL 2 POSI LOCK STUDS IN HOLES PROVIDED.)

STEP 6



1. PLACE LEFT END PANEL (ITEM 1) ON A CLEAN SCRATCH FREE SURFACE.

2. WITH 2 PEOPLE INSTALL BACK PANEL (ITEM 3) BY SLIDING ONTO POSI LOCK STUDS AND LOCKING INTO PLACE (SEE PAGE 7)

3. INSTALL THE BOTTOM (ITEM 5) USING THE SAME METHODS.

4. INSTALL THE 2 BASES (ITEM 9).

5. INSTALL THE UPPER BOTTOM (ITEM 5).

6. INSTALL THE PARTITION (ITEM 7).

7. INSTALL THE SHELF (ITEM 5).


8. INSTALL THE TOP (ITEM 4).

9. INSTALL RIGHT END PANEL (ITEM 2).

10. INSTALL THE LEVELING GLIDE INTO BOTTOM OF THE END PANELS (ITEM 1 AND ITEM 2)

11. TURN DESK UPRIGHT INSTALL 5 GROMMETS AND SLIDE DRAWERS (ITEM 8) INTO PLACE.




SHOULD YOU NEED ASSISTANCE CALL YOUR DEALER OR PARAGON AT 1-800-451-8546



CIRCULATION DESK PIECES CAN BE CONNECTED TOGETHER.

- 1.LEVEL ALL PIECES TO BE CONNECTED.
- 2.THEN USING A 13/64" DRILL BIT DRILL THROUGH THE 4 PRE-DRILLED HOLES THAT WERE NOT USED ON PAGE 3.
- 3.INSTALL SLEEVE NUT AND BOLT AND TIGHTEN.

CONNECTORS



WIRE CHANNEL INSTALLS INSIDE CABINET ONTO BACK PANEL BETWEEN GROMMETS