




PARAGON  
FURNITURE INC.




## ASSEMBLY INSTRUCTIONS FOR 32-ADA

ITEM	DESCRIPTION	QTY.
1	LEFT END	1
2	RIGHT END	1
3	BACK PANEL	1
4	TOP	1


### HARDWARE

### QTY




POSI-LOCK STUD

15



ADJUSTABLE GLIDE

4



SLEEVE NUT



4



SLEEVE NUT BOLT


4

# STEP 1



INSTALL POSI LOCK STUDS IN END PANELS (ITEMS 1&2) EXCEPT WHERE NOTED.

# STEP 2




LAY TOP PANEL (ITEM 4) ON A CLEAN SCRATCH FREE SURFACE AND INSTALL 2 POSI LOCK STUDS.


1. PLACE LEFT END PANEL (ITEM 1) ON A CLEAN SCRATCH FREE SURFACE.
2. INSTALL BACK PANEL (ITEM 3) BY SLIDING ONTO POSI LOCK STUDS AND LOCKING INTO PLACE (SEE PAGE 3)
3. INSTALL THE TOP (ITEM 4).
4. INSTALL THE RIGHT END PANEL (ITEM 2).
5. INSTALL THE LEVELING GLIDE INTO BOTTOM OF THE END PANELS.
6. TURN UPRIGHT.

SHOULD YOU NEED ASSISTANCE CALL YOUR DEALER OR PARAGON AT 1-800-451-8546

# CONNECTORS



# OPTIONAL



CIRCULATION DESK PIECES CAN BE CONNECTED TOGETHER.

- 1.LEVEL ALL PIECES TO BE CONNECTED.
- 2.THEN USING A 13/64" DRILL BIT DRILL THROUGH THE 4 PRE-DRILLED HOLES THAT WERE NOT USED ON PAGE 3.
- 3.INSTALL SLEEVE NUT AND BOLT AND TIGHTEN.