










ASSEMBLY INSTRUCTION FOR 32-HD AND 39-HD


ITEM	DESCRIPTION	QTY.
1	LEFT END	1
2	RIGHT END	1
3	BACK PANEL	1
4	TOP	1
5	SHELF/BOTTOM	2
6	BASE	2
7	DOORS	2

NOTE: ON THE 39-HD QTY OF 3

HARDWARE LIST

	<u>QTY</u>	<u>QTY</u>
	32-HD	39-HD
 POSI-LOCK STUD	36	40
 ADJUSTABLE GLIDE	4	4
 SLEEVE NUT	4	4
 SLEEVE NUT BOLT	8	8
 #6 X 3/4"	2	2
 #6 X 1/2"	4	4
 PULL	2	2
 #8 x 3/4" FLAT HEAD SCREW	8	8
 HINGE	4	4
 HINGE PLATE	4	4
 LOCK CLIP	1	1
 LOCK BODY	1	1
 DOOR LOCK CLIP	1	1
 GROMMET	5	6
 WIRE CHANNEL 24"	1	1


STEP 1



LAY END PANELS ON A CLEAN SCRATCH FREE SURFACE AND INSTALL THE HINGE PLATES.


INSTALL POSI LOCK STUDS IN HOLES EXCEPT WHERE NOTED ALSO SELECT DESIRED LOCATION FOR SHELF AND INSTALL POSI LOCK STUDS IN DESIRED HOLES.

STEP 2




LAY TOP PANEL ON A CLEAN SCRATCH FREE SURFACE AND INSTALL 2 POSI LOCK STUDS.
INSTALL LOCK CLIP USING 2 #6 X 1/2" SCREWS.

STEP 3




1. THERE ARE 2 (ITEM 5) (3 IN THE 39-HD) 1 IS THE SHELF 1 IS THE BOTTOM IN THE BOTTOM INSTALL THE 2 POSI LOCK STUDS IN THE 2 HOLES PROVIDED. THE SHELF DOES NOT REQUIRE ANY POSI LOCK STUDS.

STEP 4



1. (ITEM 7) LEFT AND RIGHT DOORS INSTALL THE 4 HINGES IN HOLES PROVIDED AND SCREW IN WITH # 8 X 3/4" SCREWS.
2. INSTALL LOCK BODY INTO LOCK HOLE WITH #6 X 3/4" SCREWS.
3. INSTALL DRAWER PULLS USING 2 SLEEVE BOLTS IN EACH PULL.
4. INSTALL DOOR LOCK CLIP ON LEFT DOOR WITH #6 X 1/2" SCREWS.

STEP 5



1. PLACE LEFT END PANEL (ITEM 1) ON A CLEAN SCRATCH FREE SURFACE.

2. WITH 2 PEOPLE INSTALL BACK PANEL (ITEM 3) BY SLIDING ONTO POSI LOCK STUDS AND LOCKING INTO PLACE (SEE PAGE 7)

3. INSTALL THE BOTTOM (ITEM 5) USING THE SAME METHODS.

4. INSTALL THE 2 BASES (ITEM 6).

5. INSTALL THE SHELF (ITEM 5).


6. INSTALL THE TOP (ITEM 4).

7. INSTALL THE RIGHT END PANEL (ITEM 2).

8. INSTALL THE LEVELING GLIDE INTO BOTTOM OF THE END PANELS.

9. TURN DESK UPRIGHT INSTALL GROMMETS AND DOORS. NOTE DOORS SLIDE INTO HINGE PLATE THEN PUSH DOWN ON BACK TO LOCK INTO PLACE ALSO DOORS CAN BE ADJUSTED FOR ALIGNMENT WITH A PHILLIPS HEAD SCREW DRIVER.




SHOULD YOU NEED ASSISTANCE CALL YOUR DEALER OR PARAGON AT
1-800-451-8546

OPTIONAL

CIRCULATION DESK PIECES CAN BE CONNECTED TOGETHER.

- 1.LEVEL ALL PIECES TO BE CONNECTED.
- 2.THEN USING A 13/64" DRILL BIT DRILL THROUGH THE 4 PRE-DRILLED HOLES THAT WERE NOT USED ON PAGE 3.
- 3.INSTALL SLEEVE NUT AND BOLT AND TIGHTEN.

CONNECTORS



WIRE CHANNEL INSTALLS INSIDE CABINET ONTO BACK PANEL BETWEEN GROMMETS