




PARAGON
FURNITURE LP.




ASSEMBLY INSTRUCTION FOR 32-CS AND 39-CS

ITEM	DESCRIPTION	QTY.
1	LEFT END	1
2	RIGHT END	1
3	BACK PANEL	1
4	TOP	1
5	SHELF/BOTTOM	2 NOTE: ON THE 39-CS QTY OF 3
6	KEYBOARD TRAY	1
7	KEYBOARD TRAY SLIDES	1 PAIR

HARDWARE LIST


PAGE 2



CAM
SCREW

QTY
32-CS

18



SHELF
SUPPORT


QTY
39-CS

18

1010588

8

8





GROMMET

4

4

STEP 1



INSTALL CAM SCREWS IN HOLES THAT ARE CIRCLED

INSTALL KEYBOARD SLIDES (ITEM 7) ONTO LEFT AND RIGHT END PANELS USING #8 X 3/4" SCREWS.

STEP 2

1. REFER TO DRAWING ON PAGE 1.
 2. LAY LEFT END PANEL (ITEM 1) ON A CLEAN SCRATCH FREE SURFACE.
 3. INSTALL BACK (ITEM3) BY SLIDING ONTO CAM SCREWS LOCK STUDS AND LOCKING INTO PLACE (SEE PAGE 3).
 4. INSTALL TOP (ITEM 4) USING THE SAME METHODS.
 5. INSTALL BOTTOM (ITEM 5).
 6. INSTALL SHELVES IN DESIRED LOCATION.
 7. INSTALL RIGHT END (ITEM 2).
 8. TURN COMPUTER STATION UPRIGHT.
 9. AFTER TURNING CABINET UPRIGHT PULL OUT KEYBOARD TRAY SLIDES
PLACE KEYBOARD TRAY (ITEM 6) ONTO TABS AND SCREW IT DOWN USING #8 X 5/8 PAN HEAD SCREWS
 10. INSTALL ADJUSTABLE SHELF
- SHOULD YOU NEED ASSISTANCE CALL YOUR DEALER OR PARAGON AT
1-800-451-8546

