




PARAGON  
FURNITURE INC.



## ASSEMBLY INSTRUCTION FOR FLAT SHELF ACCESSORY

ITEM	DESCRIPTION	QTY
1	FLAT SHELF	1
2	DEFLECTASTOP	1


1. INSTALL DEFLECTASTOP ONTO BOTTOM OF SHELF USING #6 X 3/4" SCREWS.

2. PLACE SHELF SUPPORTS IN DESIRED LOCATION .

3. INSTALL SHELF IN DESIRED LOCATION.



#8 x 3/4" FLAT HEAD SCREW (4 PER SHELF)



PUSH IN SHELF (4 PER SHELF)  
CONNECTOR

SHOULD YOU NEED ASSISTANCE CALL YOUR DEALER OR PARAGON AT  
1-800-451-8546