




**PARAGON**  
FURNITURE INC.




NOTE: IF YOU PURCHASED AN ACCESSORY BACK THE UNITIZER BRACES ITEM#3 ARE NOT NEEDED SEE PAGE 8

**LAMINATE SHELVING**


**ASSEMBLY INSTRUCTION FOR  
42-DFS, 48-DFS, 60-DFS, 72-DFS, 84-DFS**

ITEM	DESCRIPTION	9001055	9001055	9001090	9001120	9001140
		42-DFS	48-DFS	60-DFS	72-DFS	84-DFS
1	TOP	1	1	1	1	1
2	END PANEL	2	2	2	2	2
3	UNITIZER BRACES	2	2	3	3	3
4	SHELVES	6	6	8	10	12
5	ACCENT BASE	2	2	2	2	2
6	DEFLECTASTOP	6	6	8	10	12

# HARDWARE LIST



SCREW-IN TOP AND  
BOTTOM CONNECTOR  
(1010582)




PUSH IN SHELF  
CONNECTOR  
(1010583)



1/4" x 1/2"  
ATTACHING SCREW  
(1010585)




#8 x 3/4" FLAT  
HEAD SCREW  
(1010589)



ACCENT BASE CONNECTORS  
(1010584)


	QTY				
	42-DFS	48-DFS	60-DFS	72-DFS	84-DFS
SCREW-IN TOP AND BOTTOM CONNECTOR (1010582)	16	16	24	24	24
PUSH IN SHELF CONNECTOR (1010583)	16	16	16	24	32
1/4" x 1/2" ATTACHING SCREW (1010585)	42	42	54	54	54
#8 x 3/4" FLAT HEAD SCREW (1010589)	24	24	32	40	48
ACCENT BASE CONNECTORS (1010584)	4	4	4	4	4

**NOTICE: WHEN INSTALLING STARTER AND ADDERS BE SURE TO LEVEL UNITS DURING INSTALLATION TO PREVENT DAMAGE TO THE SHELVING.**

**STEP 1**


USING #8 X 3/4" FLAT HEAD SCREWS ASSEMBLE DEFLECTASTOP TO ALL SHELVES (ITEM 4).

USING 1/4" X 1/2" ATTACHING SCREWS ASSEMBLE FEMALE ACCENT BASE CONNECTORS TO ACCENT BASE (ITEM 5).

**STEP 2**

NOTE: ONLY THE 60-DFS, 72-DFS, 84-DFS HAVE THE CENTER ROW OF SCREW IN SHELF CONNECTORS


LAY END PANELS ON A CLEAN SCRATCH FREE SURFACE AND INSTALL THE SCREW-IN CONNECTORS AND MALE BASE CONNECTORS USING 1/4" X 1/2" ATTACHING SCREWS

**STEP 3**

**NOTE: IT IS RECOMMENDED THAT THESE STEPS BE DONE WITH 2 PEOPLE AND THE SHELVING UNIT STANDING UPRIGHT. THE 42-DFS AND 48-DFS DO NOT HAVE THE CENTER FIXED SHELF AND CENTER UNITIZER BRACE.**


**INSTALL UNITIZER BRACES (ITEM 3 ) WITH 1/4" X 1/2" ATTACHING SCREWS**

**NEXT INSTALL TOP (ITEM 1), CENTER AND BOTTOM SHELVES (ITEM 4) BY TAPPING ONTO THE CONNECTORS AND LOCKING THEM INTO PLACE BY TURNING SCREW IN CONNECTORS 1/2 TURN CLOCKWISE.**

**STEP 4**

INSTALL RIGHT END (ITEM 2) WITH THE SAME METHODS USED TO INSTALL LEFT END.

INSTALL ACCENT BASES (ITEM 5) BY TAPPING INTO PLACE.

**STEP 5**

**INSTALL SHELVES IN DESIRED LOCATION AND LOCK INTO PLACE**

**RECOMMENDED SHELF SPACING FROM THE BOTTOM UP**

42-DFS PIN IN THE 9 AND 19 HOLES

48-DFS PIN IN THE 10 AND 22 HOLES



60-DFS PIN IN THE 10 , 21 AND 32 HOLES

72-DFS PIN IN THE 10 , 21 , 32 AND 42 HOLES

84-DFS PIN IN THE 10 , 21 , 32 , 42 AND 52 HOLES


**NOTE: WE RECOMMEND INSTALLING ALL THE SHELF PINS BEFORE THE SHELVES**

**SHOULD YOU NEED ASSISTANCE CALL YOUR DEALER OR PARAGON AT 1-800-451-8546**




# ASSEMBLY INSTRUCTION FOR METAL SHELVING

INSTALL DEFLECTASTOP SEE STEP 1 ON PAGE 3. INSTALL METAL SHELVES USE PUSH IN PINS AND PLACE THEM IN THE DESIRED LOCATIONS NOTE THAT ON THE 60", 72" AND 84" HIGH SHELVING THE CENTER SHELF NEED TO BE SCREWED IN USING 1/4" X 1/2" ATTACHING SCREWS.




ITEM	DESCRIPTION	QTY.				
		42-DFS	48-DFS	60-DFS	72-DFS	84-DFS
1	ADJUSTABLE SHELF PINS	16	16	24	32	40






**PARAGON**  
FURNITURE INC.

**NOTE: THE SHELVING  
ACCESSORY BACK  
REPLACES THE  
UNITIZER BRACES.**



**BACK PANEL**




**ASSEMBLY INSTRUCTION FOR  
ACCESSORY BACK  
42-AB, 48-AB, 60-AB, 72-AB, 84-AB**

ITEM	DESCRIPTION	QTY.				
1	BACK PANEL					
HARDWARE		42-AB	48-AB	60-AB	72-AB	84-AB
	CAM SCREW	10	10	14	14	14


1. INSTALL CAM SCREWS INTO HOLES ALONG BACK EDGES OF SHELVING END PANELS AND SHELVING TOP SCREW INTO PANEL UNTIL SHOULDER REST ON SURFACE OF PANEL (CENTER ON DOUBLE FACED UNITS).
2. TO ASSEMBLE SHELVING UNIT HOLD END PANEL IN UPRIGHT POSITION SLIDE BACK PANEL ONTO CAM SCREWS AND LOCK INTO PLACE BY TURNING THE CAM CLOCKWISE 210 DEGREES.
3. REPEAT STEP 2 WITH THE OTHER END PANEL
4. PUSH BOTTOM SHELF ONTO CONNECTORS AND LOCK INTO PLACE BY TURNING THE SCREW IN CONNECTORS 1/2 TURN CLOCKWISE. (NOTE: YOU WILL NEED A SHORT STUBBY PHILLIPS SCREWDRIVER TO DO THIS).
5. INSTALL BASE WITH EDGE BANDED EDGE DOWN TOWARD THE FLOOR JUST LINE IT UP AND GIVE IT A FIRM PUSH ONTO THE CONNECTORS.
6. INSTALL TOP PUSH DOWN ONTO CONNECTORS AND LOCK INTO PLACE.
7. INSTALL THE REST OF THE SHELVES IN THE DESIRED LOCATION.

**ASSEMBLY INSTRUCTION  
FOR VIDEO SHELF**


Paragon 



**HARDWARE**



5 MM SHELF PIN QTY 4



DIVIDER QTY 6

1. INSTALL SHELF PINS INTO SHELVING UNIT
2. PLACE SHELF ONTO SHELF PINS
3. PLACE DIVIDER IN DESIRED LOCATIONS ALONG THE SHELF.

SHOULD YOU NEED ASSISTANCE CALL YOUR DEALER OR PARAGON AT 1-800-451-8546