


**MOBILE SHELVING**

**STEEL SHELVING**

**ASSEMBLY INSTRUCTION FOR  
42-M-DFSM, 48-M-DFSM**

ITEM	DESCRIPTION	9001058	9001058
		42-M-DFSM	48-M-DFSM
1	TOP	1	1
2	END PANEL	2	2
3	UNITIZER BRACES	2	2
4	WOOD SHELVES	2	2
5	ACCENT BASE	2	2
6	DEFLECTASTOP	6	6
7	METAL BASE FRAME (FOR CASTERS)	2	2
8	STEEL SHELVES	4	4

# HARDWARE LIST




SCREW-IN TOP AND  
BOTTOM CONNECTOR  
(1010582)

QTY  
42-M-DFSM 48-M-DFSM

16


16



STEEL SHELF PIN  
(10105881)

16

16



1/4" x 1/2"  
ATTACHING SCREW  
(1010585)

28


28



#8 x 3/4" FLAT  
HEAD SCREW  
(1010589)

8


8



#8 x 1 3/4" PAN  
HEAD SCREW  
(10105744)

20

20



4" CASTER WITH BRAKE


2

2

4" CASTER WITH OUT BRAKE  
(HRC-4)

2


2



CASTER WRENCH  
(1010965)


1

1

**STEP 1**


USING #8 X 3/4" FLAT HEAD SCREWS ASSEMBLE DEFLECTASTOP TO ALL WOOD SHELVES (ITEM 4).

USING #8 X 3/8" PAN HEAD SCREWS ASSEMBLE DEFLECTASTOP TO ALL STEEL SHELVES (ITEM 4) NOTE: ON SOME OF THE STEEL SHELVES THE DEFLECTA STOPS ARE BUILT ONTO THE SHELF.

**STEP 2**


LAY END PANELS ON A CLEAN SCRATCH FREE SURFACE AND INSTALL THE SCREW-IN CONNECTORS USING 1/4" X 1/2" ATTACHING SCREWS

# STEP 3



NOTE: IT IS RECOMMENDED THAT THESE STEPS BE DONE WITH 2 PEOPLE AND THE SHELVING UNIT STANDING UPRIGHT.

INSTALL UNITIZER BRACES (ITEM 3 ) WITH 1/4" X 1/2" ATTACHING SCREWS  
NEXT INSTALL TOP (ITEM 1), AND BOTTOM SHELVES (ITEM 4) BY TAPPING ONTO THE CONNECTORS AND LOCKING THEM INTO PLACE BY TURNING SCREW IN CONNECTORS 1/2 TURN CLOCKWISE.


**STEP 4**

INSTALL RIGHT END (ITEM 2) WITH THE SAME METHODS USED TO INSTALL LEFT END.

TURN SHELVING UNIT UPSIDE DOWN BE SURE YOU HAVE LOCKED IN ALL OF THE CONNECTORS TO PREVENT THE SHELVES FROM FALLING OUT.

INSTALL THE 2 METAL BASE FRAMES (ITEM 7) USING #8 X 1 3/4" PAN HEAD SCREWS. SCREW BASE INTO END PANELS FIRST THEN PLACE ACCENT BASE IN FRONT OF FRAME AND SCREW IT ON (NOTE THE BASES ARE NOT PRE-DRILLED).

INSTALL CASTERS TIGHTEN WITH WRENCH PROVIDED  
TURN SHELVING UNIT UPRIGHT AND INSTALL SHELVES.



**INSTALL SHELVES IN DESIRED LOCATION AND LOCK INTO PLACE**



**RECOMMENDED SHELF SPACING FROM THE BOTTOM UP**

42-M-DFSM PIN IN THE 9 AND 19 HOLES  
48-M-DFSM PIN IN THE 10 AND 22 HOLES

**NOTE: WE RECOMMEND INSTALLING ALL THE SHELF PINS BEFORE THE SHELVES**


**SHOULD YOU NEED ASSISTANCE CALL YOUR DEALER OR PARAGON AT 1-800-451-8546**

# CONNECTORS



## ASSEMBLY INSTRUCTION FOR METAL SHELVING

INSTALL DEFLECTASTOP SEE STEP 1 ON PAGE 3. INSTALL METAL SHELVES USE PUSH IN PINS AND PLACE THEM IN THE DESIRED LOCATIONS NOTE THAT ON THE 60", 72" AND 84" HIGH SHELVING THE CENTER SHELF NEED TO BE SCREWED IN USING 1/4" X 1/2" ATTACHING SCREWS.




ITEM	DESCRIPTION	QTY.				
		42-DFS	48-DFS	60-DFS	72-DFS	84-DFS
1	ADJUSTABLE SHELF PINS	16	16	24	32	40





**PARAGON**  
FURNITURE INC.


NOTE: THE SHELVING  
ACCESSORY BACK  
REPLACES THE  
UNITIZER BRACES.



**ASSEMBLY INSTRUCTION FOR  
ACCESSORY BACK  
42-AB, 48-AB, 60-AB, 72-AB, 84-AB**

ITEM	DESCRIPTION
1	BACK PANEL

**HARDWARE**



CAM  
SCREW

**QTY.**

42-AB	48-AB	60-AB	72-AB	84-AB
10	10	14	14	14

1. INSTALL CAM SCREWS INTO HOLES ALONG BACK EDGES OF SHELVING END PANELS AND SHELVING TOP SCREW INTO PANEL UNTIL SHOULDER REST ON SURFACE OF PANEL (CENTER ON DOUBLE FACED UNITS).
2. TO ASSEMBLE SHELVING UNIT HOLD END PANEL IN UPRIGHT POSITION SLIDE BACK PANEL ONTO CAM SCREWS AND LOCK INTO PLACE BY TURNING THE CAM CLOCKWISE 210 DEGREES.
3. REPEAT STEP 2 WITH THE OTHER END PANEL
4. PUSH BOTTOM SHELF ONTO CONNECTORS AND LOCK INTO PLACE BY TURNING THE SCREW IN CONNECTORS 1/2 TURN CLOCKWISE. (NOTE: YOU WILL NEED A SHORT STUBBY PHILLIPS SCREWDRIVER TO DO THIS).
5. INSTALL BASE WITH EDGE BANDED EDGE DOWN TOWARD THE FLOOR JUST LINE IT UP AND GIVE IT A FIRM PUSH ONTO THE CONNECTORS.
6. INSTALL TOP PUSH DOWN ONTO CONNECTORS AND LOCK INTO PLACE.
7. INSTALL THE REST OF THE SHELVES IN THE DESIRED LOCATION.