




PARAGON
FURNITURE LP.



MOBILE SHELVING


LAMINATE SHELVING

ASSEMBLY INSTRUCTION FOR 42-M-DFS, 48-M-DFS


ITEM	DESCRIPTION	9001057	9001057
		42-M-DFS	48-M-DFS
1	TOP	1	1
2	END PANEL	2	2
3	UNITIZER BRACES	2	2
4	SHELVES	6	6
5	ACCENT BASE	2	2
6	DEFLECTASTOP	6	6
7	METAL BASE FRAME (FOR CASTERS)	2	2

HARDWARE LIST


QTY



SCREW-IN TOP AND
BOTTOM CONNECTOR
(1010582)



PUSH IN SHELF
CONNECTOR
(1010583)




1/4" x 1/2"
ATTACHING SCREW
(1010585)




#8 x 3/4" FLAT
HEAD SCREW
(1010589)



#8 x 1 3/4" PAN
HEAD SCREW
(10105744)




4" CASTER WITH BRAKE
4" CASTER WITH OUT BRAKE
(HRC-4)




CASTER WRENCH
(1010965)


	42-M-DFS	48-M-DFS
SCREW-IN TOP AND BOTTOM CONNECTOR (1010582)	16	16
PUSH IN SHELF CONNECTOR (1010583)	16	16
1/4" x 1/2" ATTACHING SCREW (1010585)	28	28
#8 x 3/4" FLAT HEAD SCREW (1010589)	24	24
#8 x 1 3/4" PAN HEAD SCREW (10105744)	20	20
4" CASTER WITH BRAKE	2	2
4" CASTER WITH OUT BRAKE (HRC-4)	2	2
CASTER WRENCH (1010965)	1	1

STEP 1

USING #8 X 3/4" FLAT HEAD SCREWS ASSEMBLE DEFLECTASTOP TO ALL SHELVES (ITEM 4).

STEP 2


LAY END PANELS ON A CLEAN SCRATCH FREE SURFACE AND INSTALL THE SCREW-IN CONNECTORS USING 1/4" X 1/2" ATTACHING SCREWS

STEP 3

NOTE: IT IS RECOMMENDED THAT THESE STEPS BE DONE WITH 2 PEOPLE AND THE SHELVING UNIT STANDING UPRIGHT.

INSTALL UNITIZER BRACES (ITEM 3) WITH 1/4" X 1/2" ATTACHING SCREWS

NEXT INSTALL TOP (ITEM 1), AND BOTTOM SHELVES (ITEM 4) BY TAPPING ONTO THE CONNECTORS AND LOCKING THEM INTO PLACE BY TURNING SCREW IN CONNECTORS 1/2 TURN CLOCKWISE.


STEP 4

INSTALL RIGHT END (ITEM 2) WITH THE SAME METHODS USED TO INSTALL LEFT END.

TURN SHELVING UNIT UPSIDE DOWN BE SURE YOU HAVE LOCKED IN ALL OF THE CONNECTORS TO PREVENT THE SHELVES FROM FALLING OUT.

INSTALL THE 2 METAL BASE FRAMES (ITEM 7) USING #8 X 1 3/4" PAN HEAD SCREWS. SCREW BASE INTO END PANELS FIRST THEN PLACE ACCENT BASE IN FRONT OF FRAME AND SCREW IT ON (NOTE THE BASES ARE NOT PRE-DRILLED).

INSTALL CASTERS TIGHTEN WITH WRENCH PROVIDED
TURN SHELVING UNIT UPRIGHT AND INSTALL SHELVES.

STEP 5

INSTALL SHELVES IN DESIRED LOCATION AND LOCK INTO PLACE

RECOMMENDED SHELF SPACING FROM THE BOTTOM UP



42-M-DFS PIN IN THE 9 AND 19 HOLES

48-M-DFS PIN IN THE 10 AND 22 HOLES

**NOTE: WE RECOMMEND INSTALLING
ALL THE SHELF PINS BEFORE
THE SHELVES**

**SHOULD YOU NEED ASSISTANCE CALL YOUR DEALER OR PARAGON AT
1-800-451-8546**


CONNECTORS





PARAGON
FURNITURE INC.


NOTE: THE SHELVING
ACCESSORY BACK
REPLACES THE
UNITIZER BRACES.



ASSEMBLY INSTRUCTION FOR ACCESSORY BACK 42-AB, 48-AB, 60-AB, 72-AB, 84-AB

ITEM	DESCRIPTION
1	BACK PANEL

HARDWARE



CAM
SCREW

QTY.

42-AB	48-AB	60-AB	72-AB	84-AB
10	10	14	14	14

1. INSTALL CAM SCREWS INTO HOLES ALONG BACK EDGES OF SHELVING END PANELS AND SHELVING TOP SCREW INTO PANEL UNTIL SHOULDER REST ON SURFACE OF PANEL (CENTER ON DOUBLE FACED UNITS).
2. TO ASSEMBLE SHELVING UNIT HOLD END PANEL IN UPRIGHT POSITION SLIDE BACK PANEL ONTO CAM SCREWS AND LOCK INTO PLACE BY TURNING THE CAM CLOCKWISE 210 DEGREES.
3. REPEAT STEP 2 WITH THE OTHER END PANEL
4. PUSH BOTTOM SHELF ONTO CONNECTORS AND LOCK INTO PLACE BY TURNING THE SCREW IN CONNECTORS 1/2 TURN CLOCKWISE. (NOTE: YOU WILL NEED A SHORT STUBBY PHILLIPS SCREWDRIVER TO DO THIS).
5. INSTALL BASE WITH EDGE BANDED EDGE DOWN TOWARD THE FLOOR JUST LINE IT UP AND GIVE IT A FIRM PUSH ONTO THE CONNECTORS.
6. INSTALL TOP PUSH DOWN ONTO CONNECTORS AND LOCK INTO PLACE.
7. INSTALL THE REST OF THE SHELVES IN THE DESIRED LOCATION.