




PARAGON  
FURNITURE INC.




**LAMINATE SHELVING**


## ASSEMBLY INSTRUCTION FOR 42-PBDFS, 48-PBDFS, 60-PBDFS, 72-PBDFS, 84-PBDFS

ITEM	DESCRIPTION	9001055	9001055	9001090	9001120	9001140
		42-PBDFS	48-PBDFS	60-PBDFS	72-PBDFS	84-PBDFS
1	TOP	1	1	1	1	1
2	END PANEL	2	2	2	2	2
3	UNITIZER BRACES	2	2	3	3	3
4	SHELVES	4	6	8	10	12
5	ACCENT BASE	2	2	2	2	2
6	DEFLECTASTOP	4	6	8	10	12


## HARDWARE LIST



SCREW-IN TOP AND  
BOTTOM CONNECTOR  
(1010582)




PUSH IN SHELF  
CONNECTOR  
(1010583)




1/4" x 1/2"  
ATTACHING SCREW  
(1010585)



#8 x 3/4" FLAT  
HEAD SCREW  
(1010589)




PICTURE BOOK  
WIRE  
(9001485 WHEAT)  
(9001480 CB)  
(1010597 BLK)



ACCENT BASE CONNECTORS  
(1010584)


QTY				
42-DFS	48-DFS	60-DFS	72-DFS	84-DFS
16	16	24	24	24
16	16	16	24	32
42	42	54	54	54
24	24	32	40	48
16	24	32	40	48
4	4	4	4	4

**NOTICE: WHEN INSTALLING STARTER AND ADDERS BE SURE TO LEVEL  
UNITS DURING INSTALLATION TO PREVENT DAMAGE TO THE SHELVING.**


**STEP 1**

USING #8 X 3/4" FLAT HEAD SCREWS ASSEMBLE DEFLECTASTOP TO ALL SHELVES (ITEM 4).

USING 1/4" X 1/2" ATTACHING SCREWS ASSEMBLE FEMALE ACCENT BASE CONNECTORS TO ACCENT BASE (ITEM 5).

**STEP 2**


LAY END PANELS ON A CLEAN SCRATCH FREE SURFACE AND INSTALL THE SCREW-IN CONNECTORS AND MALE BASE CONNECTORS USING 1/4" X 1/2" ATTACHING SCREWS

**STEP 3**

NOTE: IT IS RECOMMENDED THAT THESE STEPS BE DONE WITH 2 PEOPLE AND THE SHELVING UNIT STANDING UPRIGHT. THE 42-DFS AND 48-DFS DO NOT HAVE THE CENTER FIXED SHELF AND CENTER UNITIZER BRACE.

INSTALL UNITIZER BRACES (ITEM 3 ) WITH 1/4" X 1/2" ATTACHING SCREWS

NEXT INSTALL TOP (ITEM 1), CENTER AND BOTTOM SHELVES (ITEM 4) BY TAPPING ONTO THE CONNECTORS AND LOCKING THEM INTO PLACE BY TURNING SCREW IN CONNECTORS 1/2 TURN CLOCKWISE.


**STEP 4**

INSTALL RIGHT END (ITEM 2) WITH THE SAME METHODS USED TO INSTALL LEFT END.

INSTALL ACCENT BASES (ITEM 5) BY TAPPING INTO PLACE.

**STEP 5**

4



**INSTALL SHELVES IN DESIRED LOCATION AND LOCK INTO PLACE**

**RECOMMENDED SHELF SPACING FROM THE BOTTOM UP**

**42-PBDFS PIN IN THE 13 HOLE**

**48-PBDFS PIN IN THE 10 AND 22 HOLES**

**60-PBDFS PIN IN THE 10 , 21 AND 32 HOLES**



**72-PBDFS PIN IN THE 10 , 21 , 32 AND 42 HOLES**

**84-PBDFS PIN IN THE 10 , 21 , 32 , 42 AND 52 HOLES**

**NOTE: WE RECOMMEND INSTALLING  
ALL THE SHELF PINS BEFORE  
THE SHELVES**

**SHOULD YOU NEED ASSISTANCE CALL YOUR DEALER OR PARAGON AT  
1-800-451-8546**

# CONNECTORS






**PARAGON**  
FURNITURE INC.

NOTE: THE SHELVING  
ACCESSORY BACK  
REPLACES THE  
UNITIZER BRACES.


BACK PANEL



## ASSEMBLY INSTRUCTION FOR ACCESSORY BACK 42-AB, 48-AB, 60-AB, 72-AB, 84-AB

ITEM	DESCRIPTION
1	BACK PANEL

### HARDWARE



CAM  
SCREW

### QTY.

42-AB	48-AB	60-AB	72-AB	84-AB
10	10	14	14	14

1. INSTALL CAM SCREWS INTO HOLES ALONG BACK EDGES OF SHELVING END PANELS AND SHELVING TOP SCREW INTO PANEL UNTIL SHOULDER REST ON SURFACE OF PANEL (CENTER ON DOUBLE FACED UNITS).
2. TO ASSEMBLE SHELVING UNIT HOLD END PANEL IN UPRIGHT POSITION SLIDE BACK PANEL ONTO CAM SCREWS AND LOCK INTO PLACE BY TURNING THE CAM CLOCKWISE 210 DEGREES.
3. REPEAT STEP 2 WITH THE OTHER END PANEL
4. PUSH BOTTOM SHELF ONTO CONNECTORS AND LOCK INTO PLACE BY TURNING THE SCREW IN CONNECTORS 1/2 TURN CLOCKWISE. (NOTE: YOU WILL NEED A SHORT STUBBY PHILLIPS SCREWDRIVER TO DO THIS).
5. INSTALL BASE WITH EDGE BANDED EDGE DOWN TOWARD THE FLOOR JUST LINE IT UP AND GIVE IT A FIRM PUSH ONTO THE CONNECTORS.
6. INSTALL TOP PUSH DOWN ONTO CONNECTORS AND LOCK INTO PLACE.
7. INSTALL THE REST OF THE SHELVES IN THE DESIRED LOCATION.