





NOTE:THE SHELVING
ACCESSORY BACK
REPLACES THE
UNITIZER BRACES.



**ASSEMBLY INSTRUCTION FOR
ACCESSORY BACK
42-AB,48-AB,60-AB,72-AB,84-AB**

ITEM	DESCRIPTION	QTY.				
1	BACK PANEL					
HARDWARE		42-AB	48-AB	60-AB	72-AB	84-AB
	CAM SCREW	10	10	14	14	14

1. INSTALL CAM SCREWS INTO HOLES ALONG BACK EDGES OF SHELVING END PANELS AND SHELVING TOP SCREW INTO PANEL UNTIL SHOULDER REST ON SURFACE OF PANEL (CENTER ON DOUBLE FACED UNITS).
2. TO ASSEMBLE SHELVING UNIT HOLD END PANEL IN UPRIGHT POSITION SLIDE BACK PANEL ONTO CAM SCREWS AND LOCK INTO PLACE BY TURNING THE CAM CLOCKWISE 210 DEGREES.
3. REPEAT STEP 2 WITH THE OTHER END PANEL
4. PUSH BOTTOM SHELF ONTO CONNECTORS AND LOCK INTO PLACE BY TURNING THE SCREW IN CONNECTORS 1/2 TURN CLOCKWISE. (NOTE: YOU WILL NEED A SHORT STUBBY PHILLIPS SCREWDRIVER TO DO THIS).
5. INSTALL BASE WITH EDGE BANDED EDGE DOWN TOWARD THE FLOOR JUST LINE IT UP AND GIVE IT A FIRM PUSH ONTO THE CONNECTORS.
6. INSTALL TOP PUSH DOWN ONTO CONNECTORS AND LOCK INTO PLACE.
7. INSTALL THE REST OF THE SHELVES IN THE DESIRED LOCATION.