




PARAGON
FURNITURE INC.




STEEL SHELVING


**ASSEMBLY INSTRUCTION FOR
42-SFS, 48-SFS, 60-SFS, 72-SFS, 84-SFS
WITH VIDEO SHELVES**

ITEM	DESCRIPTION	9001011	9001011	9001046	9001111	9001131
		42-SFS	48-SFS	60-SFS	72-SFS	84-SFS
1	TOP	1	1	1	1	1
2	LEFT END	1	1	1	1	1
3	RIGHT END	1	1	1	1	1
4	UNITIZER BRACES	2	2	3	3	3
5	BOTTOM SHELF	1	1	1	1	1
6	ACCENT BASE	1	1	1	1	1
7	DEFLECTASTOP	1	1	1	1	1
8	VIDEO SHELVES	2	2	3	4	5
9	SHELF DIVIDERS	12	12	18	24	30


HARDWARE LIST



SCREW-IN TOP AND
BOTTOM CONNECTOR
(1010582)




SHELF PINS
(10105881)




1/4" x 1/2"
ATTACHING SCREW
(1010585)




#8 x 3/4" FLAT
HEAD SCREW
(1010589)



#8 X 5/8 BLACK
PAN HEAD SCREW
(1010543)




WALL ATTACHING
BRACKET
(2281000)



ACCENT BASE CONNECTORS
(1010584)


	<u>QTY</u>				
	42-SFS	48-SFS	60-SFS	72-SFS	84-SFS
SCREW-IN TOP AND BOTTOM CONNECTOR (1010582)	8	8	8	8	8
SHELF PINS (10105881)	8	8	12	16	20
1/4" x 1/2" ATTACHING SCREW (1010585)	26	26	34	34	34
#8 x 3/4" FLAT HEAD SCREW (1010589)	4	4	4	4	4
#8 X 5/8 BLACK PAN HEAD SCREW (1010543)			2	2	2
WALL ATTACHING BRACKET (2281000)			1	1	1
ACCENT BASE CONNECTORS (1010584)	2	2	2	2	2

NOTICE: WHEN INSTALLING STARTER AND ADDERS BE SURE TO LEVEL UNITS DURING INSTALLATION TO PREVENT DAMAGE TO THE SHELVING.


STEP 1

USING #8 X 3/4" FLAT HEAD SCREWS ASSEMBLE DEFLECTA-STOP TO BOTTOM L SHLF (ITEM 5).

USING 1/4" X 1/2" ATTACHING SCREWS ASSEMBLE FEMALE ACCENT BASE CONNECTORS TO ACCENT BASE (ITEM 6).

STEP 2


LAY END PANELS ON A CLEAN SCRATCH FREE SURFACE AND INSTALL THE SCREW-IN CONNECTORS AND MALE BASE CONNECTORS USING 1/4" X 1/2" ATTACHING SCREWS

STEP 3

NOTE: IT IS RECOMMENDED THAT THESE STEPS BE DONE WITH 2 PEOPLE AND THE SHELVING UNIT STANDING UPRIGHT. THE 42-SFS AND 48-SFS DO NOT HAVE THE CENTER UNITIZER BRACE.

INSTALL UNITIZER BRACES (ITEM 4) WITH $1/4"$ X $1/2"$ ATTACHING SCREWS BE SURE THAT SCREWS ARE TOWARDS THE BACK OF THE SHELVING UNIT


NEXT INSTALL TOP (ITEM 1),AND BOTTOM SHELF (ITEM 5) BY TAPPING ONTO THE CONNECTORS AND LOCKING THEM INTO PLACE BY TURNING SCREW IN CONNECTORS $1/2$ TURN CLOCKWISE.

STEP 4

INSTALL RIGHT END (ITEM 3) WITH THE SAME METHODS USED TO INSTALL LEFT END.

INSTALL ACCENT BASE (ITEM 6) BY TAPPING INTO PLACE.



STEP 5



INSTALL SHELVES IN DESIRED LOCATION

SHOULD YOU NEED ASSISTANCE CALL YOUR DEALER OR PARAGON AT
1-800-451-8546


CONNECTORS





PARAGON
FURNITURE INC.

NOTE: THE SHELVING
ACCESSORY BACK
REPLACES THE
UNITIZER BRACES.



**ASSEMBLY INSTRUCTION FOR
ACCESSORY BACK
42-AB, 48-AB, 60-AB, 72-AB, 84-AB**

ITEM	DESCRIPTION
1	BACK PANEL

HARDWARE



CAM
SCREW

QTY.

42-AB	48-AB	60-AB	72-AB	84-AB
10	10	14	14	14

1. INSTALL CAM SCREWS INTO HOLES ALONG BACK EDGES OF SHELVING END PANELS AND SHELVING TOP SCREW INTO PANEL UNTIL SHOULDER REST ON SURFACE OF PANEL (CENTER ON DOUBLE FACED UNITS).
2. TO ASSEMBLE SHELVING UNIT HOLD END PANEL IN UPRIGHT POSITION SLIDE BACK PANEL ONTO CAM SCREWS AND LOCK INTO PLACE BY TURNING THE CAM CLOCKWISE 210 DEGREES.
3. REPEAT STEP 2 WITH THE OTHER END PANEL
4. PUSH BOTTOM SHELF ONTO CONNECTORS AND LOCK INTO PLACE BY TURNING THE SCREW IN CONNECTORS 1/2 TURN CLOCKWISE. (NOTE: YOU WILL NEED A SHORT STUBBY PHILLIPS SCREWDRIVER TO DO THIS).
5. INSTALL BASE WITH EDGE BANDED EDGE DOWN TOWARD THE FLOOR JUST LINE IT UP AND GIVE IT A FIRM PUSH ONTO THE CONNECTORS.
6. INSTALL TOP PUSH DOWN ONTO CONNECTORS AND LOCK INTO PLACE.
7. INSTALL THE REST OF THE SHELVES IN THE DESIRED LOCATION.