



INSTRUCTIONS FOR CORNER FILLER PIECE (CFP)

1. LAY CORNER FILLER PIECE FACE DOWN AND ATTACH 4 FEMALE CONNECTORS TO THE 2 ADJACENT SIDE TO BE USED.
2. USE THE DRILLING FIXTURE TO DRILL 3/16" DIA HOLES WHERE NOTED.
3. PLACE SHELVING UNITS IN DESIRED LOCATION PRESS CFP DOWN INTO PLACE.



1/4" x 1/2"
ATTACHING SCREW



ACCENT BASE CONNECTORS

QTY

16

4