




**PARAGON**  
FURNITURE INC.




NOTE: IF YOU PURCHASED AN ACCESSORY BACK THE UNITIZER BRACES ITEM#4 ARE NOT NEEDED SEE PAGE 9

**LAMINATE SHELVING**


**ASSEMBLY INSTRUCTION FOR  
42-SFS, 48-SFS, 60-SFS, 72-SFS, 84-SFS**

ITEM	DESCRIPTION	9001010	9001010	9001045	9001110	9001130
		42-SFS	48-SFS	60-SFS	72-SFS	84-SFS
1	TOP	1	1	1	1	1
2	LEFT END	1	1	1	1	1
3	RIGHT END	1	1	1	1	1
4	UNITIZER BRACES	2	2	3	3	3
5	SHELVES	3	3	4	5	6
6	ACCENT BASE	1	1	1	1	1
7	DEFLECTASTOP	3	3	4	5	6

# HARDWARE LIST



SCREW-IN TOP AND  
BOTTOM CONNECTOR  
(1010582)



PUSH IN SHELF  
CONNECTOR  
(1010583)




1/4" x 1/2"  
ATTACHING SCREW  
(1010585)




#8 x 3/4" FLAT  
HEAD SCREW  
(1010589)



#8 X 5/8 BLACK  
PAN HEAD SCREW  
(1010543)



WALL ATTACHING  
BRACKET  
(2281000)




ACCENT BASE CONNECTORS  
(1010584)

	<u>QTY</u>				
	42-SFS	48-SFS	60-SFS	72-SFS	84-SFS
SCREW-IN TOP AND BOTTOM CONNECTOR (1010582)	8	8	12	12	12
PUSH IN SHELF CONNECTOR (1010583)	8	8	8	12	16
1/4" x 1/2" ATTACHING SCREW (1010585)	26	26	34	34	34
#8 x 3/4" FLAT HEAD SCREW (1010589)	12	12	16	20	24
#8 X 5/8 BLACK PAN HEAD SCREW (1010543)			2	2	2
WALL ATTACHING BRACKET (2281000)			1	1	1
ACCENT BASE CONNECTORS (1010584)	2	2	2	2	2

**NOTICE: WHEN INSTALLING STARTER AND ADDERS BE SURE TO LEVEL UNITS DURING INSTALLATION TO PREVENT DAMAGE TO THE SHELVING.**


# STEP 1




USING #8 X 3/4" FLAT HEAD SCREWS ASSEMBLE DEFLECTASTOP TO ALL SHELVES (ITEM 5).

USING 1/4" X 1/2" ATTACHING SCREWS ASSEMBLE FEMALE ACCENT BASE CONNECTORS TO ACCENT BASE (ITEM 6).

# STEP 2



LAY END PANELS ON A CLEAN SCRATCH FREE SURFACE AND INSTALL THE SCREW-IN CONNECTORS AND MALE BASE CONNECTORS USING 1/4" X 1/2" ATTACHING SCREWS


**STEP 3**

NOTE: IT IS RECOMMENDED THAT THESE STEPS BE DONE WITH 2 PEOPLE AND THE SHELVING UNIT STANDING UPRIGHT. THE 42-SFS AND 48-SFS DO NOT HAVE THE CENTER FIXED SHELF AND CENTER UNITIZER BRACE.

INSTALL UNITIZER BRACES (ITEM 4 ) WITH 1/4" X 1/2" ATTACHING SCREWS BE SURE THAT SCREWS ARE TOWARDS THE BACK OF THE SHELVING UNIT

NEXT INSTALL TOP (ITEM 1), CENTER AND BOTTOM SHELF (ITEM 5) BY TAPPING ONTO THE CONNECTORS AND LOCKING THEM INTO PLACE BY TURNING SCREW IN CONNECTORS 1/2 TURN CLOCKWISE.


# STEP 4



INSTALL RIGHT END (ITEM 3) WITH THE SAME METHODS USED TO INSTALL LEFT END.

INSTALL ACCENT BASE (ITEM 6) BY TAPPING INTO PLACE.

# STEP 5



**INSTALL SHELVES IN DESIRED LOCATION AND LOCK INTO PLACE**



**RECOMMENDED SHELF SPACING FROM THE BOTTOM UP**

- 42-SFS PIN IN THE 9 AND 19 HOLES
- 48-SFS PIN IN THE 10 AND 22 HOLES
- 60-SFS PIN IN THE 10 , 21 AND 32 HOLES
- 72-SFS PIN IN THE 10 , 21 , 32 AND 42 HOLES
- 84-SFS PIN IN THE 10 , 21 , 32 , 42 AND 52 HOLES



**NOTE: WE RECOMMEND INSTALLING ALL THE SHELF PINS BEFORE THE SHELVES**

**SHOULD YOU NEED ASSISTANCE CALL YOUR DEALER OR PARAGON AT 1-800-451-8546**

# CONNECTORS




**WALL MOUNTING INSTRUCTIONS FOR SHELVING  
PARAGON REQUIRES ALL SINGLE FACED SHELVING  
60" OR HIGHER TO BE ATTACHED TO WALL**



#8 X 5/8 BLACK  
PAN HEAD SCREW

QTY 2



WALL ATTACHING BRACKET


QTY 1

NOTE: THE ATTACHING BRACKET CAN BE MOUNTED WITH THE FLANGE UP OR DOWN. WALL ATTACHING HARDWARE NOT INCLUDED.




**PARAGON**  
FURNITURE INC.

NOTE: THE SHELVING  
ACCESSORY BACK  
REPLACES THE  
UNITIZER BRACES.



**ASSEMBLY INSTRUCTION FOR  
ACCESSORY BACK  
42-AB, 48-AB, 60-AB, 72-AB, 84-AB**

ITEM	DESCRIPTION	QTY.				
1	BACK PANEL					
HARDWARE		42-AB	48-AB	60-AB	72-AB	84-AB
	CAM SCREW	10	10	14	14	14

1. INSTALL CAM SCREWS INTO HOLES ALONG BACK EDGES OF SHELVING END PANELS AND SHELVING TOP SCREW INTO PANEL UNTIL SHOULDER REST ON SURFACE OF PANEL (CENTER ON DOUBLE FACED UNITS).
2. TO ASSEMBLE SHELVING UNIT HOLD END PANEL IN UPRIGHT POSITION SLIDE BACK PANEL ONTO CAM SCREWS AND LOCK INTO PLACE BY TURNING THE CAM CLOCKWISE 210 DEGREES.
3. REPEAT STEP 2 WITH THE OTHER END PANEL
4. PUSH BOTTOM SHELF ONTO CONNECTORS AND LOCK INTO PLACE BY TURNING THE SCREW IN CONNECTORS 1/2 TURN CLOCKWISE. (NOTE: YOU WILL NEED A SHORT STUBBY PHILLIPS SCREWDRIVER TO DO THIS).
5. INSTALL BASE WITH EDGE BANDED EDGE DOWN TOWARD THE FLOOR JUST LINE IT UP AND GIVE IT A FIRM PUSH ONTO THE CONNECTORS.
6. INSTALL TOP PUSH DOWN ONTO CONNECTORS AND LOCK INTO PLACE.
7. INSTALL THE REST OF THE SHELVES IN THE DESIRED LOCATION.